BLACK BOX®
NETWORK SERVICES

OCTOBER 2006
LES300A
LFS400A
SERIES

Ethernet Dual SerialBridge™
Ethernet Fiber Dual SerialBridge™

CUSTOMER SUPPORT INFORMATION **Order toll-free in the U.S.: Call 877-877-BBOX (outside U.S. Call 724-746-5500) Free technical support 24 hours a day. 7 days a week: Call 724-746-5500 or fax 724-746-0746 Mailing address: Black Box Corporation. 1000 Park Drive, Lawrence, PA 15055-1018 Website: www.blackbox.com**

FEDERAL COMMUNICATIONS COMMISSION
AND
INDUSTRY CANADA
RADIO FREQUENCY INTERFERENCE STATEMENTS

This equipment generates, uses, and can radiate radio-frequency energy, and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio communication. It has been tested and found to comply with the limits for a Class A computing device in accordance with the specifications in Subpart B of Part 15 of FCC rules, which are designed to provide reasonable protection against such interference when the equipment is operated in a commercial environment. Operation of this equipment in a residential area is likely to cause interference, in which case the user at his own expense will be required to take whatever measures may be necessary to correct the interference.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This digital apparatus does not exceed the Class A limits for radio noise emission from digital apparatus set out in the Radio Interference Regulation of Industry Canada.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la classe A prescrites dans le Règlement sur le brouillage radioélectrique publié par le Industrie Canada.

Table of Content

1. Introduction 6
1.1 Features 6
1.2 Applications 8
2. Installation 11
2.1 Product Kit 11
2.2 Serial Port Operation Mode Setting 12
2.3 LED Indicator Label 14
2.4 Plug in RS232 Cable 15
2.5 Plug in Power Cable 15
2.6 Install SerialComm™ Utility 15
2.7 Initial Settings 15
2.7.1 Change Your PC/NB Settings 16
2.7.2 Change LES300A/LFS400A Series Settings 16
3. Web Browser Configuration 17
3.1 Home Page 17
3.2 Network Settings 18
3.3 Serial Port Settings 19
3.4 Restore to Default 20
3.5 Firmware Upgrade 21
3.6 Password Setting 22
3.7 Reboot 23
4. Command Mode Configuration 24
4.1 Console Port Default Settings 25
4.2 HyperTerminal Settings 25
4.3 Command Format 28
4.4 Command Sets 29
4.5 Telnet 31
5. SerialComm™ Utility 32
5.1 Define Virtual Com 34
5.2 Create and Stop Virtual Com 39
5.3 Ident-and-Connect ™ 41
5.4 Direct Connect with Discovered IP Device 43
5.5 LED Status Graphic Display 44
5.6 Ping IP Connectivity 46
5.7 Utility Version 46

6. Diagnostics – ComSR Utility 47
6.1 Install ComSR Utility 48
6.2 Open ComSR utility 49
6.3 Select COM port 50
6.4 COM Port Settings 51
6.5 Simple Terminal Simulator 52
6.6 Send/Receive Text File 54
If the transmission path has no error, then the comparison result will show Error Count: 0. 55
7. Specifications 56
8. Default Settings 58
8.1 Network 58
8.2 Serial Port 59
9. Glossary 60

Table 1 Command Sets 29

Figure 1-1 Local LAN Application – Single LES300A/LFS400A Series 8
Figure 1-2 Local LAN Application – Dual LES300A/LFS400A Series 9
Figure 1-3 Internet Application 10
Figure 2-1 LES300A/LFS400A Series Rear Panel 12
Figure 2-2 DIP Switch and Serial Port Pin Assignment Table 13
Figure 2-3 LED Indicator Label 14
Figure 3-1 Web Configuration Home Page 17
Figure 3-2 Network Settings 18
Figure 3-3 Serial Settings 19
Figure 3-4 Restore Default Settings 20
Figure 3-5 Firmware Upgrade 21
Figure 3-6 Password Settings 22
Figure 3-7 Reboot 23
Figure 3-8 Select Internet Options 24
Figure 3-9 Delete Temporary Internet Files 24
Figure 4-1 Open HyperTerminal 25
Figure 4-2 PC/NB COM Port Selection 26
Figure 4-3 PC/NB COM Port Settings 26
Figure 4-4 Ready to Accept Command 27
Figure 4-5 Open Telnet Connection 31
Figure 4-6 Command Setting via Telnet 31

Figure 5-1 Uninstall SerialComm™ 32
Figure 5-2 Stop SerialCommSvc Service 33
Figure 5-3 Start SerialCommSvc Service 34
Figure 5-4 Virtual Com Settings 35
Figure 5-5 Log Area 36
Figure 5-6 Add to Virtual Com List 37
Figure 5-7 Clear from Virtual Com List 38
Figure 5-8 Select COM port 39
Figure 5-9 Crate/Stop Virtual COM 40
Figure 5-10 Subnet Broadcast Auto Discovery 41
Figure 5-11 IP Range Auto Discovery 42
Figure 5-12 Connect with Discovered IP Device 43
Figure 5-13 Select LED Status Graphic Display 44
Figure 5-14 LED Status Graphic Display 45
Figure 5-15 Ping IP Connectivity 46
Figure 6-1 ComSR Icon 48
Figure 6-2 ComSR Window 49
Figure 6-3 Select Virtual COM 50
Figure 6-4 Com Port Settings 51
Figure 6-5 Connect Com Port 52
Figure 6-6 Simple Terminal Simulator 53
Figure 6-7 Select Com Ports 54
Figure 6-8 Send and Receive Text File 55
Figure 7-1 Network Default Settings 58

1. Introduction

The LES300A/LFS400A Series Copper/Optical Fiber Ethernet Dual SerialBridge™ easily brings a network connection to any serial device in a simple and secure manner. It enables remote accessibility for services and support to any legacy serial devices within a copper/optical fiber Ethernet environment. It combines the benefits of data network with proven asynchronous connectivity to Ethernet LANs.

The LES300A/LFS400A Series has a broad range of networking functions utilizing TCP/IP to provide serial tunneling. It is easy to set up using a secure web browser. Its flash-upgradeable firmware provides future upgradeability.

The Auto Discovery utility let user can easily find all the available LES300A/LFS400A Series in the network and can access any specific LES300A/LFS400A Series . The Virtual COM utility will treat the LES300A/LFS400A Series serial ports as the COM ports of the Windows based PC/NB running the Virtual COM utility.

The LES300A/LFS400A Series supports full and half-duplex transmission, software and hardware flow control, and has programmable baud rates for application optimization.

Overall, the LES300A/LFS400A Series will enable connections for most serial applications including retail point-of-sales, remote metering and display, industrial and building automation, security and access control and general data acquisition applications.

1.1 Features

- Easily connect all types of serial devices via IEEE 802.3 Ethernet LAN (LES300A Series) or via 100BaseFX of IEEE 802.3u Ethernet LAN (LFS400A Series)
- Comprehensive family of modes to accommodate multimode or single mode fibers, ST or SC connectors, single strand BWDM, and distance up to 120km (LFS400A Series)
- Dual serial ports, each can be RS232, RS422 or RS485 which is DIP switch selectable
- Serial ports can be set up individually via easy-to-use web browser with password protection
- Programmable baud rate (from 300bps to 115,200bps)
- Full-duplex (serial data in/data out)
- Hardware RTS/CTS flow control
- Software flow control (XON/XOF, None)
- Supports variant of protocols: TCP, UDP, IP, ICMP, HTTP, TFTP, ARP, DHCP Client, SNMP (get)
- Auto Discovery function allows available LES300A/LFS400A Series in the network to be automatically

discovered

- Includes Virtual COM function
- Supports watch dog timer
- Firmware upgrade via web browser
- Full compliment of status LEDs and activity indicators for easy installation, monitoring and diagnostics
- User friendly LED status graphic display for monitoring status remotely
- Extended operational temperature range
- Optional industrial DIN Rail mounting hardware accessory, DB9 to terminal strip or RJ-45 termination adaptor

1.2 Applications

The following describes some application examples for LES300A/LFS400A Series :

Example 1 – Local LAN Application – Single LES300A/LFS400A Series

Example 1 uses one LES300A/LFS400A Series to connect with the serial devices (for example, POS device or barcode reader) and connect to the Host PC via LAN as shown in Figure 1-1.



Figure 1-1 Local LAN Application – Single LES300A/LFS400A Series

Example 2 – Local LAN Application – Dual LES300A/LFS400A Series

Example 2 uses one LES300A/LFS400A Series to connect with the serial devices and another LES300A/LFS400A Series to connect to the Host PC, these two LES300A/LFS400A Series are connected each other via LAN as shown in Figure 1-2.



Figure 1-2 Local LAN Application – Dual LES300A/LFS400A Series

Example 3 – Internet Application

Example 3 is for far end remote communication via the Internet. LES300A/LFS400A Series serial port is connected to, for example, Programmable Logic Controller, PLC. Refer to Figure 1-3.



Figure 1-3 Internet Application

2. Installation

Please follow the steps described in Section 2.1 through 2.7 to install your LES300A/LFS400A Series including hardware and utility.

2.1 Product Kit

Before starting installation, please make sure the LES300A/LFS400A Series package includes the following four items:

1) LES300A Series or LFS400A Series
2) CD-ROM (containing SerialComm™ Utility and User's Manual).
3) Power adapter.
4) Quick Installation Guide

If anything from the above items is missing, please contact your vendor.

2.2 Serial Port Operation Mode Setting

LES300A/LFS400A Series supports dual serial ports. Each port can be a console, RS232, RS422 or RS485 port selected by the DIP switch, refer to Figure 2-1.



Figure 2-1 LES300A/LFS400A Series Rear Panel

There is a DIP switch and serial port ping assignment table attached at the bottom of LES300A/LFS400A Series . Set the serial port type based on your need, refer to Figure 2-2.

Note: The default DIP switch is set port 1 to console and port 2 to RS232. After the initial settings, remember to set the DIP switch to meet your need.

Note: After changing the DIP switch, you need to reboot the device to make the change valid. To reboot the device, you can do it via web browser or by command (console port or Telnet). Unplug and then re-plug the power can also reboot the device.

Port	Port 2		Port 1	
DIP Switch	1	2	3	4
Console	OFF	OFF	OFF	OFF
RS232	OFF	ON	OFF	ON
RS422	ON	OFF	ON	OFF
RS485	ON	ON	ON	ON

	RS232	RS422	RS485 2W	RS485 4W
1	–	Rx+	–	Rx+
2	RxD	–	–	–
3	TxD	–	–	–
4	–	Tx+	DATA+	Tx+
5	GND	GND	GND	GND
6	–	Rx-	–	Rx-
7	RTS	–	–	–
8	CTS	–	–	–
9	–	Tx-	DATA-	Tx-

Figure 2-2 DIP Switch and Serial Port Pin Assignment Table

For example,

- Set port 1 as the console port, set DIP switch 3 and 4 to OFF position (i.e. up), refer to Figure 2-1 and Figure 2-2. Port 1 LED will be all OFF.
- Set port 2 as the RS232 port, set DIP switch 1 to OFF position (i.e. up) and DIP switch 2 to ON position (i.e. down). Port 2 RS232 LED will be all ON.

2.3 LED Indicator Label

Figure 2-3 shows the LES300A/LFS400A Series LED indicator label.



Figure 2-3 LED Indicator Label

The function for each LED is described as follow:

Power LED: ON, green, when power adaptor is plugged into LES300A/LFS400A Series

Alarm LED: When power is applied to LES300A/LFS400A Series , it will do self test. During this period, the Alarm LED will be ON, red. After passing self test, it will be OFF.

When you reboot the device, the Alarm LED will also be ON during the self test period, and then it will be OFF.

Link LED: ON, green, when LES300A/LFS400A Series is linked with another LAN device.

OFF when LES300A/LFS400A Series is not linked with any LAN device

Activity LED: Blinking, yellow, when there is data transferring to/from LES300A/LFS400A Series

RS232 LED: ON, green, when the corresponding DIP switch is set to RS232

RS422 LED: ON, green, when the corresponding DIP switch is set to RS422

RS485 LED: ON, green, when the corresponding DIP switch is set to RS485

For console port, all RS232, RS422 and RS485 LED will be OFF,

2.4 Plug in RS232 Cable

Connect PC/NB to the LES300A/LFS400A Series serial port by using an NULL cross cable with DB9 female connector. This PC/NB will be used to configure LES300A/LFS400A Series via command mode. A NULL cross cable will cross pins 2 & 3, 7 & 8, and 4 & 6. LES300A/LFS400A Series can be configured either by web browser or by command mode.

2.5 Plug in Power Cable

Plug the power cord of power adapter into the socket marked with "DC IN" on the rear panel of LES300A/LFS400A Series , and plug the power adapter into an A/C power outlet. When completed, the green power LED on the top panel should light up.

Warning: Use only power adapter supplied with the LES300A/LFS400A Series ; otherwise, the LES300A/LFS400A Series may be damaged.

2.6 Install SerialComm™ Utility

Please follow the steps below to install SerialComm™ utility into the PC/NB. This utility support several functions: Virtual Com, Auto Discovery, directly connect with discovered IP devices, LED status graphic display and Ping IP connectivity.

1) Insert the supplied CD-ROM in the CD-ROM driver.

2) After inserting the CD-ROM into the driver, the SerialComm™ utility will be automatically executed. Follow the prompt instructions to finish the installation.

3) Or, directly execute the file **Setup.exe** in the CD-ROM.

2.7 Initial Settings

For setting up your LES300A/LFS400A Series at the first time, the first thing you should do is to configure the IP address and serial port settings. The PC/NB and LES300A/LFS400A Series should be within at the same IP subnet. The default IP address of the LES300A/LFS400A Series is set to:

- IP address: **192.168.1.210 (LES300A Series)**
  192.168.1.220 (LFS400A Series)

Select one of the following methods for your LES300A/LFS400A Series initial setting.

2.7.1 Change Your PC/NB Settings

Connect your PC/NB directly with LES300A/LFS400A Series LAN port (or via LAN connection).
Configure PC/NB with the following settings:

IP Address: **192.168.1.xxx** where "xxx" is a value other than 210 and 220.

Mask: **255.255.255.0**

Now, the LES300A/LFS400A Series can be configured via web browser or telnet by enter LES300A/LFS400A Series IP address: **192.168.1.210** or **192.168.1.220** (which is the LES300A/LFS400A Series default IP address, respectively).

2.7.2 Change LES300A/LFS400A Series Settings

Your PC/NB needs to be connected with LES300A/LFS400A Series serial port. Follow the steps below to configure LES300A/LFS400A Series:

- Set LES300A/LFS400A Series serial port to be the console port as described in section 2.2. The factory default DIP switch is set port 1 to console port.

  The **permanent**, default settings for console port are:

  Baud Rate: **2,400** Data Length: **8** Parity: **None**

  Stop Bit: **1** Flow Control: **None**

- Follow the steps described in section 4.1 and 4.2 to set the PC/NB COM port and open Microsoft HyperTerminal.

- Use the commands described in section 4.3 and 4.4 to change LES300A/LFS400A Series IP address. LES300A/LFS400A Series IP address should have same IP subnet as your PC/NB has.

  The commands are: **IP <IP_Address>**

  MASK <IP_Address>

  GW <IP_Address>

3. Web Browser Configuration

This section provides directions for LES300A/LFS400A Series web browser configuration: Network Settings, Serial Settings, Restore Default, Firmware Upgrade, Password Setting and Reboot the System.

3.1 Home Page

The **ETHERNET/FIBER DUAL SERIAL BRIDGE** home page will be displayed when the LES300A/LFS400A Series IP address is correctly entered into the web browser, refer to Figure 3-1. It also shows the firmware version.


ETHERNET/FIBER DUAL SERIAL BRIDGE - Windows Internet Explorer
http://192.168.1.210/
Google
ETHERNET/FIBER DUAL SERIAL BRIDGE
Page
Tools
ETHERNET/FIBER DUAL SERIAL BRIDGE
Home
Network
Serial
Restore Default
Firmware Update
Password Setting
Reboot
ETHERNET/FIBER DUAL SERIAL BRIDGE
The Ethernet/Fiber Dual Serial Bridge easily brings a network connection to any serial device in a simple and secure manner. It enables remote accessibility for services and support to any legacy serial devices within a Ethernet/Fiber environment. It combines the benefits of data networking with proven asynchronous connectivity to your LANs.
This site is optimized for IE 6.0 and 1024x768 pix or above
Version : 1.0
Done
Internet
100%

Figure 3-1 Web Configuration Home Page

3.2 Network Settings

At the left frame of the **ETHERNET/FIBER DUAL SERIAL BRIDGE** web page, select **Network** to change the IP related settings and device description information. Refer to Figure 3-2.



Figure 3-2 Network Settings

LES300A/LFS400A Series and Host PC/NB must have the same IP subnet. When the LES300A/LFS400A Series needs to connect to a Host PC that is in another subnet, then you need to specify the gateway IP address. If LES300A/LFS400A Series and Host PC are at the same subnet, then just leave Gateway IP address as it is.

The LES300A/LFS400A Series web browser configuration also provides device description information: **Alias**, **Contact**, and **Location**. Enter the information that meets your need. They are used to identify specific LES300A/LFS400A Series among several LES300A/LFS400A Series devices in same IP subnet.

3.3 Serial Port Settings

At the left frame of the **ETHERNET/FIBER DUAL SERIAL BRIDGE** web page, select **Serial** to change the serial port related settings, refer to Figure 3-3.



Figure 3-3 Serial Settings

Depend on the serial port operation mode setting, the LES300A/LFS400A Series web browser configuration will provide different display for user to enter the serial port parameter. Figure 3-3 shows that port 1 is a console port while port 2 is a RS232 port.

When the **Connection Mode** is set to **Server**, the **Remote Port** (TCP port) and **Remote IP** (IP address) filed will not show up, instead the **Local Port** (TCP port) will show up.

3.4 Restore to Default

At the left frame of the **ETHERNET/FIBER DUAL SERIAL BRIDGE** web page, select **Restore Default** to change all the LES300A/LFS400A Series settings to the factory default, refer to Figure 3-4.



Figure 3-4 Restore Default Settings

Warning: When you restore the device, the configuration settings will be reset to the factory default. Make sure you have written down the settings for record.

3.5 Firmware Upgrade

At the left frame of the **ETHERNET/FIBER DUAL SERIAL BRIDGE** web page, select **Firmware Upgrade** to upgrade LES300A/LFS400A Series firmware, refer to Figure 3-5.



Figure 3-5 Firmware Upgrade

As an ongoing development, newly released features may be available. To download the new firmware, the TFTP server must support TFTP protocol. Enter the TFTP server IP address and file name, and then click **Download and Upgrade** button to upgrade firmware.

Warning: Do not cut the power while download the new firmware. The period for loading the new firmware will depend on the IP network traffic load.

Note: When the firmware upgrade is completed, you need to reboot the device to make the change valid and then refresh the web browser; otherwise, you might get the old file from the web browser temporary Internet files.

3.6 Password Setting

At the left frame of the **ETHERNET/FIBER DUAL SERIAL BRIDGE** web page, select **Password Settings** to set the user name and password for LES300A/LFS400A Series , refer to Figure 3-6.



Figure 3-6 Password Settings

LES300A/LFS400A Series provides web browser configuration security feature through the support of the password protection function. The default username and password are:

User Name: **admin**

Password: **admin**

At the initial setting, it is recommended to change the user name and password.

3.7 Reboot

At the left frame of the **ETHERNET/FIBER DUAL SERIAL BRIDGE** web page, select **Reboot** to reboot LES300A/LFS400A Series, refer to Figure 3-7



Figure 3-7 Reboot

For any change on the settings, LES300A/LFS400A Series needs to be rebooted in order to make the change valid.

Note: When the reboot is completed, you must refresh the browser, otherwise your web browser might use the old temporary Internet file. In addition to refresh the web browser, Figure 3-8 and Figure 3-9 also shows the methods to delete the temporary Internet files.


ETHERNET/FIBER DUAL SERIAL BRIDGE - Microsoft Internet Explorer
File Edit View Favorites Tools Help
Mail and News
Pop-up Blocker
Manage Add-ons...
Synchronize...
Windows Update
Windows Messenger
Internet Options...
Back
Favorites
Address http://192.168.1.21
Go
Links
ETHERNET/FIBER DUAL SERIAL BRIDGE
Home
Network
Serial
Restore Default
Firmware Update
Password Setting
Reboot
T/FIBER DUAL SERIAL BRIDGE
The Ethernet/Fiber Dual Serial Bridge easily brings a network connection to any serial device in a simple and secure manner. It enables remote accessibility for services and support to any legacy serial devices within a Ethernet/Fiber environment. It combines the benefits of data networking with proven asynchronous connectivity to your LANs.
This site is optimized for IE 6.0 and 1024x768 pix or above
Version : 1.0
Enables you to change settings.

Figure 3-8 Select Internet Options


Internet Options
General Security Privacy Content Connections Programs Advanced
Home page
You can change which page to use for your home page.
Address: \/isapi/redir.dll?prd=ie&pver=6&ar=msnhome
Use Current Use Default Use Blank
Temporary Internet files
Pages you view on the Internet are stored in a special folder for quick viewing later.
Delete Cookies... Delete Files... Settings...
History
The History folder contains links to pages you've visited, for quick access to recently viewed pages.
Days to keep pages in history: 20 Clear History
Colors... Fonts... Languages... Accessibility...
OK Cancel Apply

Figure 3-9 Delete Temporary Internet Files

4. Command Mode Configuration

LES300A/LFS400A Series can be configured by command mode from HyperTerminal via console port or by command mode via Telnet.

Note: HyperTerminal is a Microsoft Windows™ program usually accessible from **Start**, **Programs**, **Accessories**, **Communications**, **and HyperTerminal.**

Refer to section 2.2 to set LES300A/LFS400A Series serial port as the console port.

4.1 Console Port Default Settings

When LES300A/LFS400A Series serial port is set to console mode, the console port default settings are:

Baud rate:	**2,400**
Data length (bits):	**8**
Parity:	**None**
Stop bits:	**1**
Flow control:	**None**

Note: These default values are permanent and can not be changed.

4.2 HyperTerminal Settings

From Windows, click **Start**, **Programs**, **Accessories**, **Communications**, and **HyperTerminal** to open the HyperTerminal and assign a name, e.g. LES300A as shown in Figure 4-1.

Figure 4-1 Open HyperTerminal

Select the COM port used in your PC/NB, and then click **Configure…** button for setting COM port parameters, refer to Figure 4-2.



Figure 4-2 PC/NB COM Port Selection

as LES300A Series (or LFS400A Series) console port default settings, refer to Figure 4-3.



Figure 4-3 PC/NB COM Port Settings

Set the PC/NB COM port parameters to be the same

When the PC/NB COM parameters are set complete, click **OK** button, then the following **LES300A HyperTerminal** window will be displayed. Press the **Enter** key from the PC/NB keyboard. After entering correct Username and Password, HyperTerminal will prompt "**>**" symbol and is ready to accept command, refer to Figure 4-4.



Figure 4-4 Ready to Accept Command

4.3 Command Format

The command format is:

COMMAND <parameter_1> <parameter_2>

The delimiter among command and parameters is a space. The number of parameter depends on the need of command.

Note: After using **DEFAULT** command, you need to enter the **SAVE** command in order to save the default value into the flash memory and then enter **REBOOT** to make the change valid.

Note: When a command is accepted, LES300A/LFS400A Series will respond "**OK**". If LES300A/LFS400A Series does not respond "OK", please refer to the command sets in Section 4.4, Table 1 to verify the entered command is correct or not.

Note: When the commands are all entered complete, enter **SAVE** to store the change into LES300A/LFS400A Series flash memory and then enter **REBOOT** to make the change valid.

4.4 Command Sets

The following table shows the available command sets which provide same function as web browser configuration described in section 3.

Table 1 Command Sets

Administration	
HELP	List all commands
?	Same command as HELP
DEFAULT	Restore to default
UPG <TFTP Server IP> <File Name>	Upgrade firmware through TFTP
PWD <Username> <Password>	Set username and password
CLPWD	Clear username and password
EXIT	Logout
REBOOT	Reboot System
SAVE	Save configuration to flash

Serial Settings	
BAUD <COM1|COM2> <1-10>	Select serial port (**1** or **2**) and set baud rate **1**: 300 **2**: 600 **3**: 1200 **4**: 2400 **5**: 4800 **6**: 9600 **7**: 19200 **8**: 38400 **9**: 57600 **10**: 115200
DL <COM1|COM2> <7|8>	Select serial port (**1**, **2**) and set data length (**7**, **8**)
PC <COM1|COM2> <0|1|2>	Select serial port (**1**, **2**) and set parity check **0**: None **1**: Odd **2**: Even
SB <COM1|COM2> <1|2>	Select serial port (**1**, **2**) and set stop bit (**1**, **2**)
FC <COM1|COM2> <0|1|2>	Select serial port (**1**, **2**) and set flow control **0**: None **1**: XON/XOFF **2**: Hardware
LPORT <COM1|COM2> <Local Port>	Select serial port (**1**, **2**) and set local TCP port number
RPORT <COM1|COM2> <Remote Port>	Select serial port (**1**, **2**) and set remote TCP Port number
RIP <COM1|COM2> <Remote IP Address>	Select serial port (**1**, **2**) and set remote device IP address
RMODE <COM1|COM2> <1|2>	Select serial port (**1**, **2**) and set connection mode **1**: Client **2**: Server

Network Settings

IP <IP address>	Set IP address
MASK <IP address>	Set IP Mask
GW <IP address>	Set Gateway IP address
DHCP <1|0>	Set DHCP client ON (**1**) or OFF (**0**)

System Device Information	
ALIAS <Alias Name>	Set device alias name
CONT <Contact Information>	Set device contact information
LOCT <Location Information>	Set device location information

4.5 Telnet

LES300A/LFS400A Series can also be configured by command mode via Telnet. From your PC/NB Windows, select **Start**, **Run**, and then enter "**Telnet 192.168.1.210**", for example, as shown in Figure 4-5.



Figure 4-5 Open Telnet Connection

After the Telnet connection is established, enter the username and password, then Telnet will respond the ">" prompt symbol as shown in Figure 4-6. Follow the command format and command sets in section 4.3 and section 4.4 to configure LES300A/LFS400A Series .



Figure 4-6 Command Setting via Telnet

5. SerialComm™ Utility

SerialComm™ utility provides several useful functions:

- Virtual Com function will treat the Black Box® Dual SerialBridge™ units (LWS100A, /LES300A/LFS400A Series) serial ports as the COM ports of the Windows based PC/NB running the SerialComm™ Virtual Com function.
- Ident-and-Connect™ auto discovery function lets user find all the available SerialBridge™ units in the network.
- Direct connect with the discovered IP device by clicking target device IP address.
- LED status graphic display helps user to monitor SerialBridge™ unit status remotely.
- Ping IP connectivity function will check the IP connection status between PC/NB and the specified IP device.

SerialComm™ is provided as a service with service name SerialCommSvc. When Virtual Com parameters are set up correctly, the Virtual Com ports will be automatically created by SerialComSvc service every time when you reboot your PC/NB. There is no need to start or stop SerialCommSvc service during normal operation. If you have to stop and restart SerialCommSvc service, please see **Stop SerialComm Service** section and **Start SerialComm Service** section in this chapter.

Install SerialComm

Follow the steps described in section 2.6 to install the SerialComm™ utility. After the SerialComm™ utility is installed correctly, an icon can be found at the Windows tool bar.

Uninstall SerialComm

To uninstall SerialComm™ utility from your PC/NB Windows, click **Start**, select **Programs**, **SerialComm, Diagnostic Tool** and then click **Uninstall SerialComm**, refer to Figure 5-1**.**



Figure 5-1 Uninstall SerialComm™

Open SerialComm Window

At the Windows tool bar, double click the SerialComm™ utility icon to open the **SerialComm** window for configuration LES300A.

Stop SerialCommSvc Service

At the Windows tool bar**,** select **Start, Settings, Control Panel, Administrative Tool, Service**, the following window will be displayed**.** Select **SerialCommSvc** and then click ■ button**.**


Services
File Action View Help
Stop Service
Services (Local)
SerialCommSvc
Stop the service
Restart the service
Description:
Service for SerialComm Program
N... Descri... Stat... Startup ... Log O...
Remote Procedure Call (RPC) Provid... Started Automatic Netwo...
Remote Procedure Call (RPC) Loca... Manag... Manual Netwo...
Remote Registry Enable... Started Automatic Local ...
Removable Storage Manual Local ...
Routing and Remote Access Offers ... Disabled Local ...
Secondary Logon Enable... Started Automatic Local ...
Security Accounts Manager Stores ... Started Automatic Local ...
Security Center Monito... Automatic Local ...
SerialCommSvc Service... Started Automatic Local ...
Server Suppor... Started Automatic Local ...
Shell Hardware Detection Provid... Started Automatic Local ...
Smart Card Manag... Manual Local ...
SSDP Discovery Service Enable... Started Manual Local ...
System Event Notification Tracks ... Started Automatic Local ...
Extended Standard

Figure 5-2 Stop SerialCommSvc Service

Start SerialCommSvc Service

At the Windows tool bar, select **Start, Settings, Control Panel, Administrative Tool, Service,** the following

window will be displayed. Select **SerialCommSvc** and then click button.


Services
File Action View Help
Start Service
Services (Local)
SerialCommSvc
Start the service
Description:
Service for SerialComm Program
Name
Descri...
Stat...
Startup ...
Log O...
Remote Procedure Call (RPC) Provid... Started Automatic Netwo..
Remote Procedure Call (RPC) Locator Manag... Manual Netwo..
Remote Registry Enable... Started Automatic Local ..
Removable Storage Manual Local ..
Routing and Remote Access Offers ... Disabled Local ..
Secondary Logon Enable... Started Automatic Local ..
Security Accounts Manager Stores ... Started Automatic Local ..
Security Center Monito... Automatic Local ..
SerialCommSvc Service... Automatic Local ..
Server Suppor... Started Automatic Local ..
Shell Hardware Detection Provid... Started Automatic Local ..
Smart Card Manag... Manual Local ..
SSDP Discovery Service Enable... Started Manual Local ..
Extended
Standard

Figure 5-3 Start SerialCommSvc Service

5.1 Define Virtual Com

At the upper frame of the **SerialComm** window, select **Setting** tap window to configure the Virtual Com. Figure 5-4 will be displayed and shows the existing Virtual Com settings in the **Virtual Com List**.



Figure 5-4 Virtual Com Settings

Com Port: Enter the Com port number that will be used as the Virtual Com for the PC/NB.

IP: Enter the IP address of the remote LES300A/LFS400A Series for the Com port to be mapped to.

TCP Port: Enter **Local Port** number of the remote LES300A/LFS400A Series into this field. TCP port number must be between 1024 and 65535 due to TCP port number 0-1023 are reserved for well known applications.

Add: When data is filled, click **Add** button to add this Virtual Com port into the **Virtual Com List**.

Save Configuration: Click **Save Configuration** button to save the settings into the PC/NB disk file.

Create COM Port: From the **Virtual COM List** select the virtual COM port then click this button for mapping this COM port to the corresponding IP/TCP address.

Stop COM Port: At the **Virtual COM List** select the virtual COM port then click this

button for removing the COM port <-> IP/TCP Port mapping.

As shown in Figure 5-5, at the bottom of **SerialComm** window, there is log area to show all activity. The log file can also be opened from Windows, click **Start**, select **Programs**, **SerialComm** and then click **View Log** (refer to Figure 5-1). For example,

At 2:57:15PM, there is a save configuration activity.

At 2:57:20PM, the COM3 is mapped to 192.168.1.210:1026 (IP:TCP) successfully.

At 2:57:24PM, all COM ports mapping is stop complete.



Figure 5-5 Log Area

Note: If the **Save Configuration** button is not clicked then the updated data will not be saved into the PC disk file.

Note: The connection mode of the remote LES300A/LFS400A Series should be set to **Server**.

Add to Virtual Com List

Figure 5-6 shows an example to define COM5 mapping to the LES300A/LFS400A Series with IP address 192.168.1.210 and TCP port number 1025. After clicking **Add** button, this COM port data will be added at the last line of the **Virtual Com List**. Click **Save Configuration** button to save the settings into the PC/NB disk file.



Figure 5-6 Add to Virtual Com List

Clear from Virtual Com List

From the **Virtual Com List**, select the COM port number by right clicking the row of the COM port to be deleted. For example, in Figure 5-7 the COM5 is selected, and then click **Clear** to delete COM5 from the **Virtual Com List**.



Figure 5-7 Clear from Virtual Com List

5.2 Create and Stop Virtual Com

To create and stop the Virtual Com, you must select which COM port will be activated first.

Select COM port

From the **Virtual Com List**, select the COM port number by clicking the check box under the COM column. For example, in Figure 5-8 COM 3 is selected.



Figure 5-8 Select COM port

Create/Stop Virtual COM

At the right of the **Virtual COM List**, click the **Create COM Ports** or **Stop COM Ports** button to crate the virtual COM port or stop it (refer to Figure 5-9).



Figure 5-9 Crate/Stop Virtual COM

When the Virtual COM connection is created correctly, the SerialComm™ log area will display the messages "COMx **Connect to** x.x.x.x : yyyy **OK**", For example, in Figure 5-9, at 3:07:26PM, in the log area, there is a message "**COM3 Connect to 192.168.1.210:1026 OK**" showing the COM <-> IP:TCP mapping is successfully. When the Virtual COM connection is stopped correctly, the SerialComm™ log area will display the message "Stop Complete", refer to Figure 5-9, message at 3:07:30PM.

Note: When there will be any configuration change and then reboot the LES300A/LFS400A Series device, the Virtual COM port should be stopped first.

5.3 Ident-and-Connect ™

At the upper frame of the **SerialComm** window, select **Ident-and-Connect** tap window. Figure 5-10 will be displayed. There are two methods allow user to search the available SerialBridge™ units (LWS100A, LES300A Series or LFS400A Series) in the network.

Subnet Broadcast Auto Discovery will search all the available SerialBridge™ units within the same IP subnet as PC/NB has, refer to Figure 5-10.



Figure 5-10 Subnet Broadcast Auto Discovery

Two buttons, **Start** and **Stop**, are available for user to start the search or stop the search.

It will take few seconds for searching the available SerialBridge™ units. If the target SerialBridge™ unit is found, you can use the **Stop** button to stop the search, or wait until the utility finish the search.

The Ident-and-Connect™ auto discovery function also provides the device description information: **Alias, Contact and Location** which can be used to identify a device, especially there are many SerialBridge™

family in the same location, e.g. office, factory, warehouse, etc. Those device description information are entered from, for example, LES300A Network Settings window, refer to section 3.2.

IP Range Auto Discovery allows user to specify any class C IP range for searching available SerialBridge™ units (LWS100A, LES300A Series or LFS400A Series) in that IP range, refer to Figure 5-11. The class C IP range is not necessary to be the same IP subnet as the PC/NB has. IP Range Auto Discovery supports maximum an IP class C address range, for example, from 192.168.123.100 to 192.168.123.200. **Note: Depend on the network traffic and configuration, it might take few minutes for the search.**



Figure 5-11 IP Range Auto Discovery

5.4 Direct Connect with Discovered IP Device

Ident-and-Connect™ auto discovery function also provide the capability for user to connect the PC with the target SerialBridge unit by right clicking the target device IP address and then select **Connect**. Figure 5-12 shows an example to connect device with IP address 192.168.1.212 which is an LES300A device and located at office. By clicking **Connect**, LES300A web browser configuration windows will be displayed, refer to section 3.



Figure 5-12 Connect with Discovered IP Device

If the LES300A (or LFS400A Series) web browser configuration window does not show up, refer to section 5.6 to check the IP connection.

5.5 LED Status Graphic Display

LES300A/LFS400A Series LED Status Graphic Display function provides the capability to remotely monitor LES300A/LFS400A Series device status. Right clicking the target IP device's IP address, and then click **Status**, refer Figure 5-13 and Figure 5-14.



Figure 5-13 Select LED Status Graphic Display



Figure 5-14 LED Status Graphic Display

Figure 5-14 shows an example for LES300A. The Power is ON, Ethernet link is ON. This is traffic in Ethernet port. Port 2 is set to RS232 port while Port 1 is set to console port (all LED is OFF).

5.6 Ping IP Connectivity

The Ping IP connectivity function provides an easy way to check the IP connection with the specific IP device. At the upper frame of the **SerialComm** window, select the **Ping** tap window, and then click the **Ping** button. The **Ping** function will continue to ping the specified IP device. To stop the **Ping** function, click the **Stop** button, refer to Figure 5-15.



Figure 5-15 Ping IP Connectivity

5.7 Utility Version

At the upper frame of the **SerialComm** window, select the **About** tap window to check the SerialComm™ utility version if necessary.

6. Diagnostics – ComSR Utility

Black Box® Dual SerialBridge™ units (LWS100A/LES300A/LFS400A Series) can be diagnosed by the ComSR utility which provides the loop back test to allow user to send and receive data/file from the PC/NB virtual COM via the remote SerialBridge™ two serial ports. The two serial ports will be connected by a null modem serial cable. In order to do the loop back test successfully, please make sure that:

- **Both serial ports of a SerialBridge™ unit should be set up as server ports.**
- **Two virtual Com ports should be set up by using SerialComm™, and they should start/connect successfully to the server ports of the SerialBridge™ unit.**
- **A null modem serial cable should be used to connect the two physical serial ports of the SerialBridge™ unit.**
- **Only text format is supported. Most ASCII control codes are not supported in this version.**

Note: The included Test_Text_File.txt can be used as the text file for testing sending/receiving file via the loop back path.

6.1 Install ComSR Utility

Please follow the steps below to install ComSR utility into the PC/NB.

1) Insert the supplied CD-ROM in the CD-ROM driver.

2) Read the Readme.txt file under **Diagnostic Tool** folder first.

3) Execute the file **Setup.exe** under **Diagnostic Tool** folder in the CD-ROM.

After the installation is completed, an icon will be generated as shown in Figure 6-1



Figure 6-1 ComSR Icon

6.2 Open ComSR utility

To open ComSR utility, from your PC/NB Windows, click **Start**, select **Programs**, **SerialComm, Diagnostic Tool** and then click **ComSR**, the ComSR window will be displayed as shown in Figure 6-2



Figure 6-2 ComSR Window

ComSR provide two methods for loop testing:

Terminal: ComSR is simulated as a simple terminal and allow the characters typed in one side to be shown up at the other side.

Send/Receive Text File: The text file sent in sending side will be displayed in the receiving side. The **Test_Text_File.txt** in the CD-ROM can be used for this file transfer testing.

Note: Only "Enter" and "Line Feed" ASCII control codes are supported.
Make sure the enter character or character in the text file does not include other ASCII control code.

6.3 Select COM port

Assume COM5 and COM6 have been set up via the SerialComm™, refer to section 5.1 and section 5.2 for detail on the virtual COM definition and activation.

As shown in Figure 6-3, all available COM ports can be found in the pull down window.

Select the virtual COM port, which has been setup by the SerialComm™, for both **Send** side and **Receive** side.



Figure 6-3 Select Virtual COM

6.4 COM Port Settings

ComSR supports both physical COM ports and virtual COM ports.

If the PC/NB physical COM ports are selected, then on the **Send** (and/or **Receive**) side, click the **Setting** button to set the **Com Port Setting** parameters as same values as the physical COM ports settings of your PC/NB.

If LES300A/LFS400A Series virtual COM ports are selected, then it is no matter what the **Com Port Setting** is, the ComSR can still work. This is due to the virtual COM is implemented by IP network redirector.



Figure 6-4 Com Port Settings

6.5 Simple Terminal Simulator

From the **Terminal** tap window, click the **Connect** button on both **Send** and **Receive** sides. If the connection is established correctly, the **Link** LED will be ON (green). The ComSR will be acted as if a simple terminal simulator. Any character typed in on one side will be displayed on the other side; and, the **Activity** LED will be flashing (yellow), refer to Figure 6-5 and Figure 6-6.



Figure 6-5 Connect Com Port



Figure 6-6 Simple Terminal Simulator

6.6 Send/Receive Text File

From the **Send/Receive Text File** tap window, follow the similar procedures to select and setup the COM port for both **Send** and **Receive** sides, refer to Figure 6-7.

Note 1: If the COM ports have been setup in Terminal tap windows and have not been disconnected then it not necessary to setup again.



Figure 6-7 Select Com Ports

Follow the steps below to transfer text file for loop back testing:

- At the Receive side, click **Receive/Compare File** button first.
- From the Send side click button to browse the text file to be sent and then click the **Send** button.
- The text file will be sent from the Send side and will be loop back to the Receive side via the remote LES300A/LFS400A Series two serial ports connected by one null modem serial cable. The content of the text file will be displayed at both sides. At the Receive side, the file will also be checked. A comparison result will be shown at the Receive side, refer to Figure 6-8.



Figure 6-8 Send and Receive Text File

If the transmission path has no error, then the comparison result will show **Error Count: 0.**

7. Specifications

- **Serial**
  - Baud Rate Options: 115200, 57600, 38400, 19200, 9600, 4800, 2400, 1200, 600, 300 bps
  - Data Length Options: 5, 6, 7, 8 Bits
  - Parity Options: Even, Odd, None
  - Stop Bit Options: 1, 2 Bits
  - Handshake Flow Control:
    Hardware Flow Control (RTS/CTS)
    Software Flow Control (XON/XOF, None)
  - Two Male DB9 RS232 Connectors
  - Serial UART Buffer: 4096 Bytes Input, 4096 Bytes Output

- **Power**
  - Voltage Power Source Range: 12 to 28Vdc/Vac
  - Current: 240mA Typical @ +12Vdc

- **Software**
  - No Driver Required
  - Utility: Auto Discovery and Virtual COM Software Run on Windows 95/98/Me/NT/2000/XP

- **Optical (LFS400A Series)**
  - Wavelength: 1310nm, 1530nm, or 1550nm
  - Max. TX Output (typical): -17dBm (2km)
    +3dBm (120km)
  - Sensitivity (typical): -32dBm (2km)
    -36dBm (120km)

- **Mechanical**
  - Ethernet/Fiber Port Connector: RJ-45 (LES300A Series)
    SC/ST (LFS400A Series)
  - DIP Switch for Serial Port Type Selection
  - LED: Power, Alarm, Link, Activity, RS232, RS422, RS485
  - Dimensions: 4.6" x 3.5" x 1.1"
    11.7 x 8.8 x 2.7 cm
  - Weight: 10.9 oz./310 grams

- **Environment**
  - Temperature:

Operating: -20 to +70°C / -4 to +158°F

Storage: -40 to +85°C / -40 to +185°F

- Relative Humidity: 95% (non-condensing)

• **EMC Certifications**

- FCC Part 15 Subpart A
- CE Marked

8. Default Settings

The following subsections show the default settings for LES300A Series.

For LES300A Series, the default IP address is 192.168.1.210.

For LFS400A Series , the default IP address is 192.168.1.220.

8.1 Network



Figure 8-1 Network Default Settings

8.2 Serial Port

When any serial port is set to console port, it has the following default settings:

Baud Rate: **2,400**
Data Length: **8**
Parity: **None**
Stop Bit: **1**
Flow Control: **None**

They can not be changed.

9. Glossary

Baud Rate

The number of pulses of a signal that occur in one second

Thus, baud rate is the speed the digital signal pulses travel.

Bit Rate

The transmission rate of binary symbols (.0. and .1.)

Bit rate is equal to the total number of bits transmitted in one second.

DHCP (Dynamic Host Configuration Protocol)

A protocol that automatically assigns the dynamic IP addresses to devices on a network. With dynamic addressing, a device can have a different IP address every time it connects to the network and simplifies network administration because the software keeps track of IP addresses rather than requiring an administrator to manage the task. When a device newly added into the network, a dynamic IP address will be assigned to that device. Many ISPs use dynamic IP addressing for dial-up users.

DNS

Domain Name Server is a server that translates domain names into IP addresses. A domain name is alphabetic and is meaningful for human to remember and use. However, the Internet routing is based on IP address. So, when you enter a domain name, the DNS server will translate the domain name into the corresponding IP address. For example, the domain name www.example.com might be translated to 198.152.212.140

Dynamic IP Address

In a TCP/IP network, the client station is automatically assigned an IP address by a DHCP server. The network devices, such as servers and printers, are usually assigned with static (fixed) IP addresses.

IEEE (Institute of Electrical and Electronics Engineers)

IEEE is best known for developing standards for the computer and electronics industry

CTS (Clear To Send)

An RS-232 signal sent from the receiving station to the transmitting station to indicate it is ready to accept data.

Default Gateway

The default gateway is a router used to forward all traffic that is not addressed to a station within the local subnet. The traffic will be forwarded to a destination outside of the subnet of the transmitting device.

IP Address

IP address is an identifier for a computer or device on a TCP/IP network. Networks use the TCP/IP protocol to route the messages based on the destination devices' IP address. IP address is a 32-bit numeric address written as four numbers separated by periods. Each number can be 0 to 255. For example, 192.168.1.224 could be an IP address.

Within an isolated network, the IP addresses can be assigned at random as long as each one is unique. However, to connect a private network to the Internet, it will require a registered IP addresses to avoid duplicates.

ISP (Internet Service Provider)

ISP is a company that provides service for the individuals or companies to access the Internet.

It also provides other related services such as web site and virtual hosting.

LAN (Local Area Network)

LAN is a group of computers or devices that share a common communications media and typically share the resources (e.g. server, printer) within a small area (e.g. office).

MAC Address (Media Access Control)

MAC address is a unique hardware number used to identify each node in a network.

Static IP Address

A permanent IP address that is assigned to a node in a TCP/IP network

Subnet Mask

An IP address has two components: network address and host address. Part of the host address can be used to identify a particular subnet. The system administrator can further divide the host address into two or more subnets. A mask is used to determine what subnetwork an IP address belongs to. The subnet mask is the network address plus the bits reserved for identifying the subnetwork. By convention, the bits for the network address are all set to 1 due to it will work the same if the bits were set exactly as in the network address. It's called a mask because it can be used to identify the subnet to which an IP address belongs by performing a bitwise AND operation on the mask and the IP address.

TCP (Transmission Control Protocol)

A protocol used along with the IP (Internet Protocol) to send data in message units between network devices over a LAN or WAN. IP takes care of handling the data routing and TCP takes care of tracking the individual units of data (called packets) that a message is divided into for efficient delivery over the network. TCP is a connection oriented protocol due to it requires the receiver to return an acknowledgment of receipting the packet to the sender.

TCP/IP (Transmission Control Protocol/Internet Protocol)

TCP/IP is a suite of communications protocols used to connect hosts on the Internet. It uses several protocols, the two major protocols are TCP and IP.

UDP (User Datagram Protocol)

A protocol used along with the IP (Internet Protocol) to send data in message units (datagram) between network devices over a LAN or WAN. IP takes care of handling the data routing and UDP takes care of tracking the individual units of data (called packets) that a message is divided into for efficient delivery over the network. UDP is a connectionless protocol due to it does not require the receiver to return an acknowledgment of receipting the packet to the sender (as opposed to TCP). UDP connection is not a reliable connection. It is used primarily for broadcasting messages over a network.

© Copyright 2006. Black Box Corporation. All rights reserved.

1000 Park Drive • Lawrence, PA 15055-1018 • 724-746-5500 • Fax 724-746-0746